



138

ERROR Tracking Unit

136

ECC UNIT

101

130

- 134

- 140

BUFFER UNIT

HOST SYSTEM

INTERFACE

BUFFER MEMORY

- 144

REFERENCE UNIT

HOST

142

− 100

-132

FIG. 3





